

www.safetyjogger.com

Industries:

Construction, Automotive, Chemical, Cleaning, Logistics, Mining, Oil & Gas

Environments:

Uneven surfaces, Wet environment, Warm surfaces, Dry environment, Muddy environment

Maintenance instructions:

To extend the life of your shoes, we recommend to clean them regularly and to protect them with adequate products. Do not dry your shoes on a radiator, nor nearby a heat source.

	Description	Measure unit	Result	EN ISO 20345
Upper	Leather			
	Upper: permeability to water vapor	mg/cm²/h	7.1	≥ 0.8
	Upper: water vapor coefficient	mg/cm²	64	≥ 15
Lining	Membrane			
	Lining: permeability to water vapor	mg/cm²/h	2.4	≥ 2
	Lining: water vapor coefficient	mg/cm²	23	≥ 20
Footbed	SJ foam footbed			
	Footbed: abrasion resistance (dry/wet) (cycles)	cycles	25600/12800	25600/12800
Outsole	PU/Rubber (NBR)			
	Outsole abrasion resistance (volume loss)	mm³	75	≤ 150
	Outsole slip resistance SRA: heel	friction	0.36	≥ 0.28
	Outsole slip resistance SRA: flat	friction	0.44	≥ 0.32
	Outsole slip resistance SRB: heel	friction	0.14	≥ 0.13
	Outsole slip resistance SRB: flat	friction	0.19	≥ 0.18
	Antistatic value	MegaOhm	16.4	0.1 - 1000
	ESD value	MegaOhm	52	0.1 - 100
Toecap	Composite			
	Impact resistance toecap (clearance after impact 100J)	mm	N/A	N/A
	Compression resistance toecap (clearance after compression 10kN)	mm	N/A	N/A
	Impact resistance toecap (clearance after impact 200J)	mm	18.5	≥ 14
	Compression resistance toecap (clearance after compression 15kN)	mm	21	≥ 14

Sample size: 42

Our shoes are constantly evolving, the technical data above may change. All product names and brand Safety Jogger, are registered and may not be used or reproduced in any format, without written consent from us.



Solutions for every workplace

INDUSTRIAL PROFESSIONAL TACTICAL TIGER GRIP



www.safetyjogger.com